

Capping a Wall

MULTIPIECE SYSTEM INSTALLATION GUIDELINES

STRAIGHT WALL

Trapezoidal caps must be laid alternately short and long faces for a straight line. Rectangular caps should have the finished side out. Always start capping from the lowest elevation.

OUTSIDE CURVES

Lay out the cap units side by side and cut at least every other cap to produce a uniform look. Start with the long side of the cap facing out and adjust to the radius.

INSIDE CURVES

Lay cap units side by side with the short side facing out. In most circumstances, making two cuts on one cap and then not cutting the cap on either side produces the most pleasing look.

CORNERS





On a 90° corner wall, the corner caps need to be saw-cut to achieve a 45° mitered corner.

STEPPING UP CAPS

If a wall elevation changes, caps can be stacked where the wall steps up. Begin laying caps at the lowest elevation change and work your way back toward the previous step up. Split* or cut a cap unit to fit. Place the split unit directly on top of the capped portion of the wall with all three split faces exposed.

FINISHING

After layout is complete and caps are saw-cut or split to size, carefully glue with a concrete adhesive.



**To split a block, use a hydraulic splitter or split manually by using a hammer and chisel to score the block on all sides. Pound the chisel on the same line until the block splits. If partial unit sides are not exposed, use a circular cut-off saw with a masonry blade to achieve a tighter fit.*

© 2011 Anchor Wall Systems, Inc. Anchor™ retaining wall systems are manufactured under license from Anchor Wall Systems, Inc. (AWS). The "Anchor Build Something Beautiful" logo is a trademark of AWS. The wall system blocks are covered by the AWS Limited Warranty. For a complete copy, visit your local dealer or see anchorwall.com. All rights reserved.

Anchor Wall Systems, Inc., 5959 Baker Road, Suite 390, Minnetonka, MN 55345.
A&B0925 72.3298.1 12/11 4023