

COURSE A

PLACE ADDITIONAL PANEL AT CORNER
TO PROVIDE 100% GEOGRID COVERAGE
OF REINFORCED FILL. THIS PANEL
SHOULD BE PLACED ONE COURSE
ABOVE MAIN REINFORCEMENT.

USE A MASONRY SAW TO
ACHIEVE DESIRED ANGLES.
CUT UNITS TO MAINTAIN
RUNNING BOND.

COURSE B

NOTE:

FREE-DRAINING AGGREGATE (NOT SHOWN) TO SPAN 10 FT. ALONG THE WALL FACE AND TO THE BACK OF THE REINFORCED ZONE



© 2015 Anchor Wall Engineering, LLC
® and ™ Anchor Wall Systems, Inc.
www.anchorwall.com

This drawing is for illustrative purposes only and should not be used for construction without the signature of a registered professional engineer.

Vertica® Straight Face Retaining Wall System
Inside Angles

Scale:	Drawn by:
1/4" = 1'-0"	JB
Date:	Drawing number:
	VTST32
	/