


# WALL CAP END



## MULTI-PIECE SYSTEM

## INSTALLATION INSTRUCTIONS



### END A WALL WITHOUT A COLUMN

End installation pattern next to a wall end unit if the wall does not end with a column.

Cut every other wall end unit in half. Glue all units.

If a wall end unit is not available in your market, either:

- See your dealer for a template to guide cutting corner/column and wall units to finish end; or
- Visit [anchordiamond.com](http://anchordiamond.com) for installation instructions and construction details.



### FINISH WITH CAP END UNIT

- If a cap unit needs to be cut, cut an interior cap, not a cap end unit. Place and glue cap end to finish capping wall.
- Cap end unit may also be used for capping a corner and for step-downs.
- Visit [anchordiamond.com](http://anchordiamond.com) for installation instructions and construction details.



© 2022 ANCHOR Diamond® retaining wall systems are manufactured under license from ANCHOR Diamond®. The wall system blocks are covered by the Anchor Diamond® Limited Warranty. For a complete copy, visit your local dealer or see [anchordiamond.com](http://anchordiamond.com). All rights reserved.

**Anchor Diamond®**  
5909 Baker Rd. Suite 550 • Minnetonka, MN 55345  
AWS22-253 05/22